TEMPERATURE DATA LOGGERS' REQUIREMENT FOR IMPORT REFRIGERATED AND FROZEN FOODS

Quality and Safety

Dear Walmart, Central America Supplier:

A critical element in maintaining food quality and safety is the cold chain; ensuring all our products are storage and transported in the correct temperatures, is possible through the proper monitoring of the cold chain; for this, we ask the use of 2 temperature data loggers in each Walmart shipment; one must be a Real-Time tracker and one Built-in USB Port, only from the list of authorized models listed below, which offers 5 options. These trackers are required on every frozen, refrigerated, and controlled temperature product shipments inbound to our Central America food distribution centers and manufacturing plants.

The suggested combinations are:
a. 1 real-time monitoring sensor + 1 USB port sensor
b. 2 real-time monitoring sensors

The authorized models of the temperature data loggers with real-time monitoring are the Copeland Go Real-Time and Sensitech's TempTale GEO, which provide complete temperature visibility throughout the entire import transit, from the moment the container is loaded at origin to unloading at the Walmart dock. However, to obtain the maximum benefit from these models, it is imperative that they be scheduled, as only in this manner can we identify the imports and obtain the complete information generated by the online monitoring platforms; which are for Copeland https://portal.oversight360.copeland.com/ and for Sensitech https://sensiwatch.com/. The programming instructions for both providers are shared separately.

The approved temperature data logger's models with a USB port are the Deltatrak FlashLink RTL Mini 31010 and the Copeland GO PDF Mini which are quick and easy to program and generate the information required to analyze cold chain compliance.

The list of authorized brands and models is:

AUTHORIZED BRANDS AND REAL-TIME TRACKERS MODELS

BRAND	MODEL	CHARACTERISTICS	IMAGE	CONTACT			
				Country	**Name**	**Phone**	**Email**
Copeland	GO Real-Time XL 4G/5G TXC-TH04	* Temperature measurement range: -20° C to 60° C (- 4° F to 140° F) * Duration in use: up to 60 days * Real-time information access system: Oversight Platform * Generation of readings and graphs * Battery life: 6 months		United States of America	Meg McNeill	+1 336-314-0579	CargoOrders@copeland.com
				Mexico	Soporte Comercial		Cargolatinamerica@copeland.com
				Central America and the Caribbean	Gabriela Chavez	+52 33 1411 8693	Gaby.Chavez@Copeland.com
				Perú, Ecuador, Colombia and Brasil	Daniel Cobos	+52 33 1011 4974	Daniel.Cobos@Copeland.com
				Chile, Argentina, Paraguay and Uruguay	Matías Barros	+56 9 5894 2362	Matias.Barros@Copeland.com
				Europe	Sergio Castro	+33 645596338	Cargoeurope@Copeland.com
				Country	**Name**	**Phone**	**Email**
Sensitech	TempTale GEO Eagle	* Temperature measurement range: -30° C to 55° C (-22° F to 131° F) * Duration in use: 7 to 90 days * Real-time information access system: SensiWatch Platform * Battery life: 3 months NOTE: Works only on 2G cellular networks. Not recommended for use in the United States, Canada, Chile, South Korea, and Japan.		United States of America	Customer service	9789277033	sensitech.clientservices@carrier.com
				México	Customer service	525541814931	sensitech.mexico@carrier.com
				Guatemala, El Salvador, Honduras, Nicaragua, Costa Rica	Customer service	56233212845	sensitech.chile@carrier.com
				Brasil	Customer service	551933998650	sensitech.brazil@carrier.com
Sensitech	TempTale GEO LTE	* Temperature measurement range: -30° C to 55° C (-22° F to 131° F) * Duration in use: up to 30 days | Extended: 90 days * Real-time information access system: SensiWatch Platform * Battery life: 6 months NOTE: It operates on the Cat M1 and 2G LTE networks. This device is recommended for increased operation in various countries of origin and destination.		Ecuador, Peru, Colombia	Alvaro Bucaram	593999515515	abucaram@jaiaclatam.com
				Uruguay, Paraguay, Argentina	Jose Luis Pieroni	59899627157	jpieroni@nibacor.com
				Chile	Ivan Labetić	56968343509	ilabetic@carrier.com
				Continent	**Name**	**Phone**	**Email**
				Europe	Customer service	31252211108	sensitech.clientservicesEMEA@carrier.com
				Asia	Customer service	85228800780	sensitech.apac@carrier.com

TEMPERATURE DATA LOGGERS' REQUIREMENT FOR IMPORT REFRIGERATED AND FROZEN FOODS

Walmart México y Centroamérica

Quality and Safety

AUTHORIZED BRANDS AND BUILT-IN USB PORT MODELS				
BRAND	**MODEL**	**CHARACTERISTICS**	**IMAGE**	**CONTACT**
Deltatrak	FlashLink RTL Mini 31010	* Temperature measurement range: -40° C to 60° C (-40° F to 140°F) * Duration in use: 85 days * Built-in USB port * Generation of readings and graphs * Battery life: 18 months		https://www.deltatrak.com/
Copeland	GO PDF Mini TM60D-EMR00	* Temperature measurement range: -20° C to 40° C (- 4° F to 104° F) * Duration in use: up to 60 days * Built-in USB port * Generation of readings and graphs * Battery life: 12 months		**Country** / **Name** / **Phone** / **Email** United States of America — Meg McNeill — +1 336-314-0579 — CargoOrders@copeland.com Mexico — Soporte Comercial — Cargolatinamerica@copeland.com Central America and the Caribbean — Gabriela Chavez — +52 33 1411 8693 — Gaby.Chavez@Copeland.com Perú, Ecuador, Colombia and Brasil — Daniel Cobos — +52 33 1011 4974 — Daniel.Cobos@Copeland.com Chile, Argentina, Paraguay and Uruguay — Matías Barros — +56 9 5894 2362 — Matias.Barros@Copeland.com Europe — Sergio Castro — +33 645596338 — Cargoeurope@Copeland.com

Other requirements and instructions:

- **The physical location and the serial numbers must be listed in the Packing List and BL.**
- **Make sure temperature data loggers are settled to bring information (date/hour/temperature) in periods of 10 -15 minutes (Asia and Europe no longer than 1 hour between records). If the sensor is not programmed or is programmed incorrectly, the defense against claims based on the absence of temperature data from the import becomes invalid.**
- Paper temperature data loggers or graphic-printed thermal recorders are not accepted under any circumstances, without exception. Neither are models or brands, other than those detailed in this document.
- Ensure that the sensor batteries have sufficient life to cover the trip, plus any unforeseen events.
- The trackers/temperature data logger must be placed in the superior carton layer, not directly in the container walls or doors; if the load is at double pallet, the tracker/sensor must be placed in the superior pallet. Do not use excess of stretch film to secure it (these may interfere in the temperature record).
- Each tracker/temperature data logger must be identified with a note as below (page size):

Place the temperature data logger here.

Termógrafo
Temperature data logger


de serie: _____

"No tocar – No quitar – No apagar"

Este dispositivo registra la temperatura de la carga



- **First tracker location:** must be the Real-Time tracker and needs to be placed in the pallet next to the door (pallet #1 or #11 and if it is at double pallet, in the #21 or #31).
- **Second tracker location:** must be the Built-in USB Port and needs to be placed in the pallet in the middle of the truck (pallet #6 or #16 and if it is at double pallet, in the #26 or #36).



Location # 1: Real Time data logger

Location # 2: Data logger with USB port

This letter supersedes and replaces any prior specifications, agreements, representations, or understandings, whether written, oral, or implied, between you and Walmart regarding this subject matter.
This new update will take effect on January 1st, 2027.

Thank you,

Walmart Merchandising Team, Logistic Team and Quality and Safety Team

Walmart